

# How to debug a DLL or EXE



Views:

## Authored By

Michael Humphreys, Sandrine Auriol and Tim Gustafson

## Abstract

This article shows two techniques to debug a User Defined DLL or a User Defined EXE.

- The first one is to write "debugged" values in a text file.
- The second one is to attach the Visual Studio debugger to a running process. It is shown here using Microsoft Visual Studio Community 2017.

## Contents

- Debug using a text file
- Debug using Visual Studio debugger
  - Compile the DLL or EXE in Debug Mode
  - Back to OpticStudio
  - Attach to Process
  - Set Breakpoints
  - Run the DLL/EXE
  - Stop the debugger
  - Distributing the DLL/EXE in Release Mode

## Downloads

Article Attachments ([https://downloads.zemax.com/Zemax-portal/knowledge\\_articles/KA-01636/Downloads/Lambertian\\_DebugText.zip](https://downloads.zemax.com/Zemax-portal/knowledge_articles/KA-01636/Downloads/Lambertian_DebugText.zip)) ([http://downloads.zemax.com/Zemax-portal/knowledge\\_articles/KA-01636/Downloads/Lambertian\\_DebugText.zip](http://downloads.zemax.com/Zemax-portal/knowledge_articles/KA-01636/Downloads/Lambertian_DebugText.zip))

This article shows how to debug User Defined DLL or EXE created in Visual Studio in C, C++ or C#. The steps to create those User Defined features are not detailed here.

## Debug using a text file

One way to debug a User Defined DLL or a User Defined EXE is to write "debugged" values in a text file. Let's add some debugging lines to the user-defined scattering function {Zemax}\DLL\SurfaceScatter\Lambertian.c. The modified file called Lambertian\_DebugText.cpp can be found in the attachments.

First, to write in a text file, the following libraries are added at the top of the code:

```
#include <fstream>
#include <sstream>
#include <iostream>
#include <shlobj.h>
using namespace std;
```

Then a "DebugBool" parameter is defined:

```
int __declspec(dllexport) APIENTRY UserParamNames(char *data)
{
    ...
    //debug
    if (i == 3) strcpy(data, "DebugBool");
    return 0;
}
```

Depending on the value of the "DebugBool" parameter, a file is created and values can be written in that file for further analysis:

```
bool debug = data[54] != 0;

...

CHAR my_documents[MAX_PATH];
fstream debuglog;
string filepath;
if (debug)
{
    SHGetFolderPath(NULL, CSIDL_PERSONAL, NULL, SHGFP_TYPE_CURRENT, my_documents);
    filepath = string(my_documents) + "\\Zemax\\DLL\\SurfaceScatter\\debug.txt";
    debuglog.open(filepath, ios::out | ios::app); // debuglog.close();
    debuglog.precision(12);
}

...


debuglog << debugged_value << "\t";
debuglog.close();
```

As can be seen, writing a text file to debug is an easy method.



## Debug using Visual Studio debugger

### Compile the DLL or EXE in Debug Mode

Let's see how to compile a DLL or EXE in Debug Mode. For example, let's compile a user defined surface (DLL). For more details, see the article "How to compile a User-Defined DLL" (~/Knowledge-Base/kb-article/?ka=KA-01787).



Once compiled, 2 files need to be copied from Project\Debug to {Zemax}\DLL\Surfaces: the DLL and the PDB file. Normally (when using the DLL in release mode), only the DLL file is copied. But the PDB file (Program database) is needed here because it stores debugging information about programs.



Every time the DLL is modified and recompiled, it will have to be manually copied again from Project\x64\Debug to {Zemax}\DLL\Surfaces.

To avoid this, the "Project\x64\Debug" output folder can be changed to {Zemax}\DLL\Surfaces:


In C++: in Visual Studio, go to Solution Explorer. Select the project. Right-click, go to Properties. The project Property pages opens. Under Configuration Properties, select General. Change the Target Name.

In C#: in Visual Studio, go to Project Preferences > Build > Output directory.

## Back to OpticStudio


Open OpticStudio and select the User Defined Surface or Operand.

- User Defined Surface DLL: change Surface 2 to a User Defined Surface. Surface 2 is using the DLL in Debug mode:



	Surface Type	Comment	Radius	Thickness	Material	Coating	Semi-Diameter	Chip Zone	Mech Semi-Dia	Conic	TCE x 1E-6
0	OBJECT	Standard ▾	Infinity	Infinity			0.00000000...	0.0000...	0.00000000...	0.0...	0.0000...
1		Standard ▾	Infinity	5.000...			5.25000000...	0.0000...	5.25000000...	0.0...	0.0000...
2	STOP (aper) User Defined ▾	Offset_Surface.dll	38.88...	3.000...	BK7		6.00000000...	U -	-	0.0...	-
3	(aper)	Standard ▾	Infinity	72.78...			6.00000000...	U 0.0000...	6.00000000...	0.0...	0.0000...
4	IMAGE	Standard ▾	Infinity	-			8.11721018...	0.0000...	8.11721018...	0.0...	0.0000...

- User Defined Operand UDOC: select the UDOC operand in the Merit Function. Make sure to set the Timeout (ms) to a high value so that the UDOC can be debugged in Visual Studio without having OpticStudio throw a timeout error.



Type	Prog#	Data	Hx	Hy	Px	Py	Timeout (ms)	Target	Weight
1 UDOC ▾	1	0	0.0000	0.0000	0.0000	0.0000	1.0000E+06	0.0000	0.0000


At this point, do not update the system or the Merit Function yet. An update will execute the user defined surface or UDOC. If there are errors in the code, it may cause a crash.


## Attach to Process

Back to Visual Studio, everything is ready to start debugging. If the user extension is a DLL, the debugger can be attached to the OpticStudio.exe process. If the user extension is an EXE, the debugger can be attached to our application process.

## DLL Method – Attach to OpticStudio

The debugger can be attached to the OpticStudio running process :





The Attach to box will select the type of code to be debugged.

- In C++ it will be **Native code**
- In C# it will be **Managed code**

In Available Processes, make sure to select the appropriate OpticStudio process. It may be easier to have only one OpticStudio instance open.

## EXE Method – Attach Directly To UDOC

To debug a UDOC, the UDOC application itself is attached to the process rather than OpticStudio. Therefore, a “pause” is set in the UDOC code. It can be a `Console.ReadKey()` for C# or `system(“pause”)` for C++ to pause the actual execution.


In C#, the code might look like below:

```


74
75 // Initialize the output array
76 int maxResultLength = TheApplication.OperandResults.Length;
77 double[] results = new double[maxResultLength];
78
79 Console.WriteLine("Attach debugger (Ctrl+Alt+P) then press any key...");
80 Console.ReadKey();
81 Console.WriteLine("Proceeding with code");
82
83 IOpticalSystem TheSystem = TheApplication.PrimarySystem;
84

```

If the Merit Function is updated, a Command Line Window will open and display a message :



Now, the UDOC can be attached to the debugger. Make sure to have the correct code selected for the UDOC. Below, "Managed code" is selected as the code is in C++.



Note that with a UDOC, the process needs to be attached every time the Merit Function is updated.

## Set Breakpoints

Then let's set a few breakpoints inside the DLL code to investigate the values being passed.

```

30  int __declspec(dllexport) APIENTRY UserDefinedSurface(USER_DATA *UD, FIXED_DATA *FD)
31  {
32      int i, loop;
33      double p2, alpha, power, rad, casp, t, zc, tp, x, y, z, dz, sag;
34
35  switch(FD->type)
36  {
37      case 0:
38          /* ZEMAX is requesting general information about the surface */
39          switch(FD->numb)
40          {
41              case 0:
42                  /* ZEMAX wants to know the name of the surface */

```

## Run the DLL/EXE

In OpticStudio, clicking on the User Defined Surface or updating the Merit Function with the UDOC operand will run the DLL or EXE and start the debugger. Back to Visual Studio, a yellow arrow is displayed on the breakpoint. It shows the code that will be executed next.

The window DEBUG > WINDOWS > LOCALS displays the values being passed between the DLL and OpticStudio. In that window, two types of data structures are passed: User Data (UD) and Fixed Data (FD).

110 %

Name	Value
alpha	-9.2559631349317831e+61
casp	-9.2559631349317831e+61
dz	-9.2559631349317831e+61
FD	0x000000910adef7c0 {type=0 numb=2 surf=2 ...}
i	-858993460
loop	-858993460
p2	-9.2559631349317831e+61
power	-9.2559631349317831e+61
rad	-9.2559631349317831e+61
sag	-9.2559631349317831e+61
t	-9.2559631349317831e+61
tp	-9.2559631349317831e+61
UD	0x000000910adef700 {x=3.077794996670e-312#DEN y=6.952080346295e-310#DEN z=0.0000000000000000}
x	3.077794996670e-312#DEN
y	6.952080346295e-310#DEN
z	0.0000000000000000

Autos Locals Watch 1



## User Data UD

It contains the rays x, y, z locations on a plane tangent to the surface vertex (the DLL will compute and return them for the real surface), the ray direction cosines l, m, n and the surface normals ln, mn, nn (which are computed and returned) and other data like index, transmission, path length.

Locals		
Name	Value	Type
UD	0x000000910adef700 {x=3.077794996670e-312#DEN y=6.952080346295e-310#DEN z=0.0000000000000000 ...}	USER_DATA *
x	3.077794996670e-312#DEN	double
y	6.952080346295e-310#DEN	double
z	0.0000000000000000	double
l	0.0000000000000000	double
m	0.0000000000000000	double
n	0.0000000000000000	double
ln	0.0000000000000000	double
mn	0.0000000000000000	double
nn	0.0000000000000000	double
path	0.0000000000000000	double
sag1	0.0000000000000000	double
sag2	0.0000000000000000	double
index	0.0000000000000000	double
dndx	0.0000000000000000	double
dndy	0.0000000000000000	double
dndz	0.0000000000000000	double
rel_surf_tran	0.0000000000000000	double
udreserved1	0.0000000000000000	double
udreserved2	0.0000000000000000	double
udreserved3	0.0000000000000000	double
udreserved4	0.0000000000000000	double
string	0x000000910adef7a8 ""	char[20]

## Fixed Data FD


It mainly contains data the DLL cannot change: the surface data in the Lens Data Editor (radius, conic, parameters, etc.), the ray wavelength, polarization state and Type and Numb parameters indicating what data OpticStudio wants from a given call to the DLL.

Locals		
Name	Value	Type
FD	0x000000910adef7c0 {type=0 numb=2 surf=2 ...}	FIXED_DATA *
type	0	int
numb	2	int
surf	2	int
wave	1	int
wavelength	0.550000000000000004	double
pwavelength	0.550000000000000004	double
n1	1.000000000000000000	double
n2	1.5185223876207927	double
cv	0.025714093365970001	double
thic	3.000000000000000000	double
sdia	6.000000000000000000	double
k	0.000000000000000000	double
param	0x000000910adef810 {0.0000000000000000, 0.0000000000000000, 0.0000000000000000, 0.0000000000000000, ...}	double[9]
fdreserved1	0.000000000000000000	double
fdreserved2	1.000000000000000000	double
fdreserved3	1.5185223876207927	double
fdreserved4	0.000000000000000000	double
xdata	0x000000910adef878 {0.0000000000000000, 0.0000000000000000, 0.0000000000000000, 0.0000000000000000, ...}	double[201]
glass	0x000000910adefec0 "BK7"	char[21]

For example, FD -> n2 shows the index of refraction of N\_BK7 being passed from OpticStudio to the DLL.

## Stop the debugger

To stop the debugger, click on the red Square in Visual Studio.



## Distributing the DLL/EXE in Release Mode

After debugging the DLL/EXE, the configuration can be changed back from Debug to Release. The libraries for Debug configurations are not redistributable while the libraries for Release configurations are redistributable.

Two techniques to debug a User Defined feature were demonstrated. The 1st one showed how to write a debug text file. The 2nd one showed how to use Visual Studio Debugger in the case of a DLL (User Defined Surface) and an EXE (User Defined Operand).

Both methods can be applied for any User Defined capabilities that OpticStudio has: DLL, User Defined Operands, ZOS-API User Extensions and ZOS-API User-Analysis.

## References

- Attach to Running Processes with the Visual Studio Debugger: <https://msdn.microsoft.com/en-us/library/3s68z0b3.aspx> (<https://msdn.microsoft.com/en-us/library/3s68z0b3.aspx>)
- Navigating through Code with the Debugger: <https://msdn.microsoft.com/en-us/library/y740d9d3.aspx> (<https://msdn.microsoft.com/en-us/library/y740d9d3.aspx>)

Keywords: ZOS-API, Programming, EXE, DLL, User Defined

### Sign up for our blog

Don't miss out on key insights, best practices, and news from Zemax.

\* BUSINESS EMAIL:

**SUBMIT**

### SUPPORT

[Forum \(/forum/\)](#)

[Cases \(/support/cases/\)](#)

[Support by Phone \(/support/support-by-phone/\)](#)

### RESOURCES

[Knowledgebase \(/Knowledge-Base/\)](#)

[Consultants \(/consultants/\)](#)

[Software Downloads \(/downloads/\)](#)

[MyZemax FAQ \(/myzemax-faq/\)](#)

[License Policies \(/Licensing-Policies/\)](#)



[\(https://www.facebook.com/ZemaxLLC/\)](https://www.facebook.com/ZemaxLLC/)



<https://twitter.com/ZemaxLLC>



[\(https://www.linkedin.com/company/zemax-llc/\)](https://www.linkedin.com/company/zemax-llc/)



<https://www.youtube.com/user/RadiantZemaxLLC>

[Privacy policy \(/privacy-policy/\)](#), [License Agreements \(/license-agreements\)](#), [Terms of service \(https://my.zemax.com/en-US/Account/Login/TermsAndConditions?ReturnUrl=%2Fen-US%2F&UseExternalSignInAsync=True&IsFacebook=False\)](#), [Cookie Policy \(/cookie-policy\)](#), [Provide Feedback \(mailto:webmaster@zemax.com\)](#), [Staff Login \(/Account/Login/ExternalLogin?returnUrl=/&provider=https://login.windows.net/354fdc29-20d2-4db2-8c26-daffa2a0b61e/\)](#)